

Reel Holder


ASSEMBLY INSTRUCTIONS

CAUTION

INSPECT CONTENTS IMMEDIATELY AND FILE CLAIM WITH DELIVERING CARRIER FOR ANY DAMAGE.

SAVE YOUR BOX AND ALL PACKING MATERIALS.

YOU ARE RESPONSIBLE FOR DAMAGE TO YOUR UNIT IF RETURNED IMPROPERLY PACKED.



Parts List

<i>qty</i>	<i>part #</i>	<i>description</i>
2	A200816	plastic split sleeve
2	A209887	hanger bracket
1	36" or 48" or 60"	reel tube
2	A201602	hair pin cotter

1 Split Sleeves

Install split sleeves on rear posts where reel holder is to be located. The thicker part of the split sleeve should be towards the bottom.

2 Hanger Bracket

Slide hanger bracket down rear vertical posts and seat on split sleeves with hanger brackets facing each other.

3 Reels

Mount reels onto reel tube and place reel tube into hanger bracket channel. Slide hair pin cotter into hole on hanger bracket.

Note: For static discharge, please order aluminum split sleeves (not included).



Profit from the Eagle Advantage™

EG9950 Revised 06/02